



# DJI Phantom 3 Advanced Battery Replacement

Remove your battery to begin part replacement or replace a dead battery in order to continue flying.

Written By: Quinn Tirpak



## INTRODUCTION

This guide will outline the steps required to remove the battery from the DJI Phantom 3 Advanced. This is the first step for any other repair process, and can also be used to replace your battery with a fully charged one.

## Step 1 — Battery



- With the battery facing you, locate the two tabs on the top and bottom of the battery as shown.

⚠ Remember to disarm and power down your quadcopter before beginning any disassembly.

## Step 2



- Press the two tabs with your finger and thumb, and gently slide the battery towards you, out of the quadcopter frame.
- With your other hand, be sure to hold the quadcopter steady to ensure that it stays still.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 07:28:30 AM.